

POLAR KETTLE 2.6 litre

INSTRUCTIONS



The Polar Kettle is made from aluminium to disperse heat evenly and quickly and has a practical volume of 1.97 litres.

1. Place snow and at least 1cm of water into the kettle, close the lid
2. Hook a notch on the shank onto the brace for single-hand pouring
3. Ensure the shank is kept outside the flame guard during stove operation
4. Store and transport your kettle with care. Crimping of the lid or kettle rim will increase steam production and lower fuel efficiency.
Use an optional Lid Lock or Kettle Pouch.

NOTE: On longer expeditions it is useful to bring a small amount of 2-part metal repair compound.

