





NAVIMOUNT

COMPASS SUPPORT INSTRUCTIONS

INCLUDED

1. Navimount bar with attached end toggles and support cord
2. Neck extension and Connector Cords for non-Icetrek harnesses



FOR USE WITH ICETREK HARNESES

1. Hook Navimount bar end toggles (a) into gear loops (b) on both sides of Icetrek harness waist belt.
2. Attach Velcro tabs (c) on ends of support cord (d) to Velcro strips on Icetrek harness shoulder pads, adjusting up or down as required.
3. Insert your compass into slots (e) on Navimount bar (ensuring a minimum of two corners of your compass base plate engage with slots) and secure by sliding lock (f) forward.
4. Adjust cord length (g) to keep your compass level

FOR USE WITH OTHER HARNESES

1. Tie included connector cords (h) to convenient points on either side of your harness waist belt.
2. Attach the included neck extension (i) to Velcro tabs (c) to form a loop.
3. Hook Navimount bar end toggles (a) into the connector cords then place cord loop over your head.
4. Insert your compass into slots (e) on Navimount bar (ensuring a minimum of two corners of your compass base plate engage with slots) and secure by sliding lock (f) forward.
5. Adjust cord length (g) to keep your compass level

