

REKLINER INSTRUCTIONS


Regular ☐

Large ☐



ICE TREK
polar equipment
www.icetrek.com

Lay out your Rekliner with the seat rods on the underside. Place your mattress inside the zippered sleeve ensuring that any corner valves are located at the top right corner (when laying on your back). This allows air to be expelled from the mattress as you roll it up for transport or storage. Inflate your mattress and zip the sleeve closed, ensuring the zip sliders are placed next to the valve for easy access.




The foot canopy can be used to protect your sleeping bag foot box from touching icy or damp tent walls.



To deploy the chair, lift head section and connect side buckles. Adjust straps as required.

Rods can be removed through an opening in the rod sleeve.



For transportation, leave your mattress inside your Recliner and store folded in thirds, half or unfolded. The more folds, the more air needs to be expelled from your mattress. Use the straps to secure the folds.



Your Recliner can be rolled up empty or with the deflated mattress inside.

Lay your Recliner out with rods underneath, head section on your right.

Fold the foot section into the middle then the head section (the logo should now be on top). Tuck straps in, leaving the far long strap exposed.

Roll away from you, expelling air as you go (if you have your mattress inside).

Wrap far seat strap around your Recliner once or twice and clip into securing buckle.

