

PARTS 2 x boot harness

1. Mount shims and plates to your skis then bindings to your shims (see Section 1: *Mounting Instructions for Flexi Ultima System*)
2. Determine Left and Right bases. Arrow on base plate points to outside of binding. Right-foot binding is illustrated, start with this binding.
3. Select a boot harness and feed the shortest buckle stem (A) (Inset 1) through the front outside cam slots (B) leaving 2cm of tail (Inset 2). Repeat with long buckle stem (C) in rear cam slots (D) on same side.
4. Feed the corresponding long straps (E) through the opposing cam slots on the inside wall. Buckles will be located on the outside of the binding.
5. Repeat procedures with Left binding.
6. Use the Release Cord (F) to loosen straps completely. Step into Right binding from rear placing boot under both straps.
7. Pull Tensioning Loop (G) firmly up and across boot to fasten boot into binding. The loop should be big enough to accommodate your largest glove or mitten when the binding is fully released. Alter the length by adjusting the straps in the cam slots. Once preferred strap length is achieved Repeat with Left boot.
8. If you have excessive play between your boots and the sidewalls use optional Bolsters (H) to take up the slack (Inset 3).
9. To exit from your bindings, pull downward on the Release Cord (F). Alternatively place the tip of your ski pole into the Release Cord and push downward and outward using the pole basket. Apply even pressure on both buckles for a smooth release. After some use the straps will run smoothly through the buckles and memorise the shape of your boots.

